

# BF-430

## User Manual



Document Version 1.0

Web Version realcom 2009-02-07

Firmware Version 1.13.00, Apr 4 2011


# 【Index】

I 、 Hardware Introduction.....	1
II 、 Product Overview.....	3
III 、 WEB Login .....	4
IV 、 Web Function Instruction .....	10
One Page Quick Setup.....	10
Advanced Setup.....	13
1 、 Operation Mode Setup .....	13
(1)TCP Server .....	13
(2)TCP Client.....	14
(3)UDP Server .....	15
(4)UDP Client .....	16
2 、 Serial Port Setup .....	17
3 、 DDNS Setup.....	18
(1)TZ0.....	18
(2) Dyn dns.....	19
Management .....	20
1 、 Device Administration Setting.....	20
2 、 System Status Monitor .....	21
3 、 Backup & Restore Configuration .....	22
4 、 Firmware Upgrade.....	23
5 、 PING .....	24

# — BF-430 —

## I 、 Hardware Introduction

### ◆ Appearance



### ◆ Specification


Item	Specification
<b>Ethernet Interface</b>	10/100Base-T, half/full duplex
<b>Signal Port</b>	RS232/485/422
<b>RS232 Signal</b>	TxD, RxD, RTS, CTS, DTR, DSR, DCD, GND, Baud Rate: 1200bps~230.4kbps
<b>RS485 Signal</b>	2 wire Data+/- (only for BF-430)
<b>RS422 Signal</b>	4 wire R+/R-/T+/T- (only for BF-430)
<b>CPU</b>	16 bit CPU, 100MHz
<b>Memory</b>	256K ROM & 768K SDRAM
<b>Watch Dog</b>	System never halts
<b>I/O Support</b>	No
<b>LED</b>	4, Power / RXD / TXD / ACT
<b>Power Requirement</b>	DC 9~30V, 300 mA
<b>Power Requirement</b>	300mA(9V)
<b>EMI/EMC Certification</b>	FCC B, CE B
<b>System Requirement</b>	Operation temperature 0 ~ 65°C Storage temperature -20 ~ 85°C Operation humidity: 5 ~ 95%
<b>Surge Protection</b>	Serial port 15 KV ESD
<b>Magnetic Protected</b>	Ethernet port 1.5 KV
<b>Connector Type</b>	DB9(Male)/RJ-45
<b>Reset Button</b>	Yes

## ◆ End point

### ● RS-232 pin definition(DB-9)

Pin No.	Abbreviation	Name
1	CD	Carrier Detect
2	RXD	Receive Data
3	TXD	Transmit Data
4	DTR	Data Terminal Ready
5	GND	Signal Ground
6	DSR	Data Set Ready
7	RTS	Request To Send
8	CTS	Clear To Send
9	RI	Ring Indicator

POWER	1 LED RED	Power Input signal
TRANS	1 LED GREEN	Action Indicator signal
100M	1 LED RED	Network transmission signal
LINK	1 LED RED	Network connection signal



## II 、 Product Overview

BF-430 is a RS232/RS485 converter for the integration of system and Ethernet management, designed and applied to enable traditional industrial serial devices to access data and control devices through Ethernet (intranet or internet)

Real time operation system and complete TCP/IP protocol enable CHIYU's BF-430 powerful converter not only providing complete system with highly efficiency but also able to link with network. Easy to install and wire. The Web interface of BF-430 is simple, easily to operate, and without operation system limitation.

### ◆ Features

- BF-430 support 4 kinds of connection: TCP server / client 及 UDP server / client, Users can select suitable connecting way.
- Support DHCP Client, when activate this function, BF-430 can get TCP/IP default from DHCP Server when the system activates, Includes IP address, default gateway IP and DNS server.
- Support PPPoE, PPPoE is an internet protocol for the link simulation of dial-up connection and remote host.
- Support Dynamic DNS, this enable BF-430 connect with dynamic IP by fixed Domain Name, enable hosts situated in different location to get access to BF-430 through internet.
- Auto detecting 10/100 M Ethernet.
- Enable users to conduct data access or management on BF-430 through various operation system of IE , Netscape browser.
- Allows users to back up and store file system parameter and restore it, for security reasons the backup file will be stored encrypted.

### III 、 WEB Login

BF-430 contains a HTTP server, thus BF-430 can link and connect through Web browser, and then conduct setting.

#### ◆ Preparation

Before conducting BF-430 setting, please assure the following:


- PC has connected to BF-430, and PC and BF-430 are situated in the same WAN with power supplied.
- If the default IP address (192.168.168.125) is occupied by else device, then it is a must to shut down that device first till the setting is over, and then allocate new IP address to BF-430.

#### ◆ How to search BF-430

1、After installation of BF-430 and network cable is completed, use BF-430's [IP Search](#) to search all BF-430 in a certain LAN, or download IP Search tool from [CHIYU](#) homepage. Desktop icon as below:



2、Click IP Search icon, will display a window, as shown:



The screenshot shows the IP Search Ver1.1 application window. At the top, there is a table with the following data:

Device Name	Location	Model Name	IP Address	Subnet mask	Gateway	MAC Addr
1 CHYU		BF430 232/485 TCP/IP Converter	192.168.168.125	255.255.255.0	192.168.168.254	00 0E E3

Below the table, the software displays detailed information for the selected device:

**Atheros L2 Fast Ethernet 10/100Base-T Controller**

Active Route :  
 IP Address : 192.168.0.33  
 Subnet Mask : 255.255.255.0  
 Gateway : 192.168.3.1


IP Address : 192 . 168 . 168 . 125  
 Subnet Mask : 255 . 255 . 255 . 0  
 Gateway : 192 . 168 . 168 . 254  
 Mac Address : 00 0E E3 01 36 46

Search options:  
 Broadcast  
 Specific IP Address  
 192.168.168.125


PS:  
 IP 192.168.0.0 scan  
 192.168.0.1~192.168.0.255  
 IP 192.168.0.66 only scan  
 192.168.0.66

Buttons: Refresh, Alter, Exit


3、While the IP Search window shows up, it will display all BF-430 in LAN, and show its **Device name**, **Location**, **Model Name**, **IP Address**, **Subnet Mark**, **Gateway**, **Mac Address**. Select particular BF-430, then its related information will appear below the window, as shown:



4、The showed information of BF-430 can be revised directly in the window, the part can be modified: IP Address, Subnet Mask, Gateway. After modification completed ( **MAC Address can not modify** ),click **Alter** then it will display the modified information, as shown:



5、After modification, if want to confirm whether the modification is correct or not, click [Refresh](#) button to refresh and check information ( Fig-1 ), click [Exit](#) button to leave.(Fig-2)



6、After modification, the IP address of BF-430 has matched with its WAN, if want to get access into the Web of BF-430, has two methods:

- (1)Open IP Search, select and double click particular BF-430, then to enter its webpage.
- (2)While the internet explorer opened, input BF-430 IP address to enter its webpage

**Remark :**


**WINDOWS XP :**

《 Step 1 》

Click WINDOWS XP my computer  , Open Control Pan  Control Panel on the left side, please turn to traditional overview and select network link

《 Step 2 》

Click LAN, then select content, the link configuration will be shown, click Internet Protocol (TCP/IP), then input the same setting as BF-430, as below figure:




## WINDOWS 7 :

《 Step 1 》

Click Windows 7 icon,  select  Control Panel , open and search for ,  Network and Sharing Center click Alter Interface Card on the upper-left side.

《 Step 2 》

Click LAN link, select content, then the LAN settings will be shown, click Internet Protocol(TCP/IPv4) , then input the same setting as BF-430, as below figure:




## ◆ How to login to BF-430 Web via web browser

1、Start Web browser ( eg: WIN 7 IE ), input BF-430's IP Address, for example: use the default BF-430 IP Address: <http://192.168.168.125>

2、If connection failed, should check:

- If BF-430 installed and its power supplied properly
- To examine the LAN connection, can use start tools→Execute→Input cmd open MS-DOS, Input “ ping” to test BF-430 connection, input command: ping 192.168.168.125, as shown below:



```
Administrator: C:\Windows\system32\cmd.exe - ping 192.168.168.125
Microsoft Windows [Version 6.1.7600]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.
C:\Users\en-chiyu>ping 192.168.168.125
Pinging 192.168.168.125 with 32 bytes of data:
```

- If no response received, it explains the link has troubles either the connection is not proper or the PC's IP address can not match with BF-430's IP address
- Set the PC's IP address with BF-430's IP address with same segment, if the PC uses fixed IP address, the address must be ranged in: 192.168.168.1 ~ 192.168.168.65 or 192.168.168.67 ~ 192.168.168.254 , thus it can be compatible with BF-430's default IP address: 192.168.168.125, the **Subnet Mask's** setting must be: 255.255.255.0, [please refer to page 6 ~ 7](#)

3 · If the connection with BF-430 is successful, then it will display a message window for User name and Password, the default for user name and Password is: **admin/admin**, as shown below:




4 · While the user name and password entered, a Web setting interface of BF-430 will be showed, enter it will then display a “ **One Page Quick Setup** “ page.




## IV 、 Web Function Instruction

### ◆ One Page Quick Setup



#### ● Function instruction of STATIC IP

Function	Description
IP Address	Set the IP address of the BF-430 , default setting is <b>192.168.168.125</b>
Subnet mask	Set the subnet mask of the BF-430 , default setting is <b>255.255.255.0</b>
Gateway	Set the gateway of the BF-430 , default setting is <b>192.168.168.254</b>
Primary DNS	Set the DNS of the BF-430 , default setting is <b>168.95.1.1</b>
Serial Port Mode	
Serial Type	Set the serial type, RS232 and RS485 for setting , default setting is <b>RS232</b>
Baud Rate	1.Set serial port baud rate, the parameters can be selected : <b>1200 、 2400 、 4800 、 9600 、 19200 、 38400 、 57600 、 115200 、 230400 and Others</b> 2.After selecting <b>Others</b> , fill custom baud rate into the user defined 3.Default setting is <b>19200</b>
Operation Mode	
Connection Mode	There are <b>4 modes</b> to set into connection mode, such as : <ul style="list-style-type: none"> <li>● TCP Server</li> <li>● TCP Client</li> <li>● UDP Server</li> <li>● UDP Client</li> </ul>
Connection Port Number	Set BF-430 connection port number, default setting is <b>50000</b>
Remote Host IP Address (For Client Only)	1.Set the remote host IP address, the default setting is <b>0.0.0.0</b> 2. <b>For Client Only</b>



● **Function instruction of DHCP CLIENT**

Function	Description
Host Name (optional)	Fill in the host name , default setting is <b>CHIYU</b> (optional)
<b>Serial Port Mode</b>	
Serial Type	Set the serial type, RS232 and RS485 for setting , default setting is <b>RS232</b>
Baud Rate	1. Set serial port baud rate, the parameters can be selected : <b>1200</b> 、 <b>2400</b> 、 <b>4800</b> 、 <b>9600</b> 、 <b>19200</b> 、 <b>38400</b> 、 <b>57600</b> 、 <b>115200</b> 、 <b>230400</b> and <b>Others</b> 2. After selecting <b>Others</b> , fill custom baud rate into the user defined 3. Default setting is <b>19200</b>
<b>Operation Mode</b>	
Connection Mode	There are <b>4 modes</b> to set into connection mode, such as : <ul style="list-style-type: none"> <li>● <b>TCP Server</b></li> <li>● <b>TCP Client</b></li> <li>● <b>UDP Server</b></li> <li>● <b>UDP Client</b></li> </ul>
Connection Port Number	Set BF-430 connection port number, default setting is <b>50000</b>
Remote Host IP Address (For Client Only)	1. Set the remote host IP address, the default setting is <b>0.0.0.0</b> 2. <b>For Client Only</b>




● **Function instruction of PPPoE**

Function	Description
User Name	Fill in the user name, up to <b>47</b> characters
Password	Fill in the password, up to <b>35</b> characters
Service Name (optional)	Fill in the service name (optional), up to <b>47</b> characters
Close Connection when Idle Time Over	<ul style="list-style-type: none"> <li>● Default setting is <b>0 second</b>, the range is from 0 ~ 4294967295</li> <li>● Keep the connection of BF-430 and ISP always must set the no into 0 or the connection with PPPoE will be disabled when Idle time over.</li> </ul>
PPPoE with Fixed IP Address	<ul style="list-style-type: none"> <li>● After selecting <b>ENABLE</b> , fill in fixed IP</li> <li>● Default setting is <b>DISABLE</b></li> <li>● optional</li> </ul>
Serial Port Mode	
Serial Type	Set the serial type, RS232 and RS485 for setting , default setting is <b>RS232</b>
Baud Rate	1. Set serial port baud rate, the parameters can be selected : <b>1200</b> 、 <b>2400</b> 、 <b>4800</b> 、 <b>9600</b> 、 <b>19200</b> 、 <b>38400</b> 、 <b>57600</b> 、 <b>115200</b> 、 <b>230400</b> and <b>Others</b> 2. After selecting <b>Others</b> , fill custom baud rate into the user defined 3. Default setting is <b>19200</b>
Operation Mode	
Connection Mode	There are <b>4 modes</b> to set into connection mode, such as : <ul style="list-style-type: none"> <li>● <b>TCP Server</b></li> <li>● <b>TCP Client</b></li> <li>● <b>UDP Server</b></li> <li>● <b>UDP Client</b></li> </ul>
Connection Port Number	Set BF-430 connection port number, default setting is <b>50000</b>
Remote Host IP Address (For Client Only)	1. Set the remote host IP address, the default setting is <b>0.0.0.0</b> 2. <b>For Client Only</b>

## ◆ Advanced Setup

### 1、Operation Mode Setup


#### (1)TCP Server



#### ● Function instruction

Function	Description
Local Listen Port Number	<ul style="list-style-type: none"> <li>● If data transmit thru TCP/IP remote command, must select Serial Server Mode into TCP SERVER and set LISTEN PORT NUMBER into the same value with monitoring side.</li> <li>● Default setting is <b>50000</b></li> </ul>
Close Connection When Remote Idle	<ul style="list-style-type: none"> <li>● The default setting of close connection time is <b>100</b> seconds and the range is from 0 ~ 32768</li> <li>● The value must set to be 0 if you want to keep BF-430 connect with monitoring side or the connection will be off automatically when remote idle.</li> </ul>
Access Password	<ul style="list-style-type: none"> <li>● Make sure the data secure, user must set the code for management. User must inset the correct password and process the further procedure after authority.</li> <li>● up to <b>31</b> characters</li> </ul>
Keep Alive Check	<ul style="list-style-type: none"> <li>● Set Enable or Disable keep alive check function , default setting is <b>Disable</b></li> <li>● While keep alive check enable, the pin packet will be send to Gateway every <b>30 seconds</b> to make cure the connection.</li> </ul>
Max TCP Connection	The maximum TCP connection is <b>4 sets</b> , default setting is <b>1</b>
Real COM	When using the <b>Virtual COM</b> , if you need BF-430 with VCOM to send each other RTS / CTS, DTR / DSR signal, this option must be checked


## (2)TCP Client



### ● Function instruction

Function	Description
Remote Connection Port Number	Set the remote connection port number , the range is 0 ~ 65535 , default setting is <b>50000</b>
Remote Host IP Address	Set remote host IP address , default setting is <b>0.0.0.0</b>
TCP Connection	<ul style="list-style-type: none"> <li>● There are 2 modes to set TCP connection to server :               <ol style="list-style-type: none"> <li>1.<b>Start Up</b> : This mode means when BF-430 enable, it will build the TCP connection with SERVER immediately. It will automatically build the TCP connection after disable and then re-connect again.</li> <li>2.<b>Any Character</b> : This mode means only when BF-430 receives data from RS232/485, it will build TCP connection with SERVER. TCP connection will be disable if not receiving the data from RS232/485.</li> </ol> </li> </ul>


### (3)UDP Server



● **Function instruction**

Function	Description
Local Listen Port Number	<ul style="list-style-type: none"> <li>● If data transmit thru UDP remote command, must select Serial Server Mode into UDP SERVER and set LISTEN PORT NUMBER into the same value with monitoring side.</li> <li>● Default setting is <b>50000</b></li> </ul>


## (4)UDP Client



### ● Function instruction

Function	Description
Remote Connection Port Number	Set the remote connection port number , the range is 0 ~ 65535 , default setting is <b>50000</b>
Remote Host IP Address	Set the remote host IP address, the default setting is <b>0.0.0.0</b>

## 2 · Serial Port Setup




Serial Type	RS232
Baud Rate	19200 (User Defined)
Data Bits	8
Parity Check	None
Stop Bits	1
Flow Control	None
Force Packet Transmit Time	0 (0 - 65535)ms
Force Packet Transmit Length	0 (0 - 65535)bytes
Delimiter 1	0x 00 (HEX) <input type="radio"/> Enable <input checked="" type="radio"/> Disable
Delimiter 2	0x 00 (HEX) <input type="radio"/> Enable <input checked="" type="radio"/> Disable
RS485 Transmission Delay Time	0 (0 - 65535)us <i>Note: for RS485 only</i>

### ● Function instruction

Function	Description
Serial Type	Set the serial type, RS232 and RS485 for setting , default setting is <b>RS232</b>
Baud Rate	1.Set serial port baud rate, the parameters can be selected : <b>1200</b> 、 <b>2400</b> 、 <b>4800</b> 、 <b>9600</b> 、 <b>19200</b> 、 <b>38400</b> 、 <b>57600</b> 、 <b>115200</b> 、 <b>230400</b> and <b>Others</b> 2.After selecting <b>Others</b> , fill custom baud rate into the user defined 3.Default setting is <b>19200</b>
Data Bits	Set the data bits , 5,6,7,8 parameters can be selected, default setting is <b>8</b>
Parity Check	<ul style="list-style-type: none"> <li>● Set the parity check , <b>4 parameters</b> can be selected :               <ol style="list-style-type: none"> <li>1.<b>odd</b></li> <li>2.<b>Even</b></li> <li>3.<b>Mark</b></li> <li>4.<b>Space</b></li> </ol> </li> <li>● Default setting is <b>None</b></li> </ul>
Stop Bits	Set the stop bits , 1,2 parameters can be selected, default setting is <b>1</b>
Flow Control	Set the flow control , 2 parameters can be selected : <ul style="list-style-type: none"> <li>● Xon/Xoff : Software flow control</li> <li>● CTS/RTS : Hardware flow control</li> <li>● Default setting is <b>None</b></li> </ul>
Force Packet Transmit Time (ms)	<ul style="list-style-type: none"> <li>● Force packet transmit time</li> <li>● The minimum setting is 0 ms of setting serial interval between data. Default setting is <b>0</b>,the range is 0~65535ms</li> </ul>
Force Packet Transmit Length (bytes)	<ul style="list-style-type: none"> <li>● Force packet transmit length.</li> <li>● The serial set length of data transmission range is from 0~ 65535 bytes, the default setting is <b>0</b></li> </ul>
Delimiter 1	<ul style="list-style-type: none"> <li>● Set the transmission data end by identified delimiter and if your transmission data includes the identified delimiter, BF-430 will send out packet at once.</li> <li>● Default setting is <b>disabled</b>. The range is from 0x00 ~ 0xFF</li> </ul>
Delimiter 2	<ul style="list-style-type: none"> <li>● Set the transmission data end by identified delimiter and if your transmission data includes the identified delimiter, BF-430 will send out packet at once.</li> <li>● Default setting is <b>disabled</b>. The range is from 0x00 ~ 0xFF</li> </ul>
RS485 Transmission Delay Time	Set the RS485 transmission delay time, range is 0 ~65535us, the default setting is <b>0</b>

### 3、DDNS Setup


#### (1)TZ0



● **Function instruction**

Function	Description
E-mail Address	Fill in the E-mail address for DDNS , up to <b>47</b> characters
Password key	Fill in the password key for DDNS , up to <b>31</b> characters
Device DNS Name	Fill in the device DNS name , for example : hostname.tzo.com
Registry IP Address	Display the registry IP address , when DDNS is enabled, It will show the registry IP address
Status	Display DNS Serve status , when DDNS server does not enable ,it will show <b>“DDNS function is disabled”</b>

## (2) Dyndns



**DDNS Setup**

DDNS Services:

Username:	<input type="text" value=""/> (maximum 31)
Password:	<input type="text" value=""/> (maximum 31)
Device DNS Name:	<input type="text" value="hostname.dyndns.org"/> (ex. hostname.dyndns.org)
Registry IP Address :	0.0.0.0
Status :	DDNS function is disabled

### ● Function instruction

Function	Description
Username	Fill in the username for DDNS , up to <b>31</b> characters
Password	Fill in the password for DDNS , up to <b>31</b> characters
Device DNS Name	Fill in the device DNS name , for example : hostname.dyndns.org
Registry IP Address	Display the registry IP address , when DDNS is enabled, It will show the registry IP address
Status	Display DNS Serve status , when DDNS server does not enable ,it will show <b>"DDNS function is disabled"</b>

## ◆ Management


### 1、Device Administration Setting



### ● Function instruction

Function	Description
Block Standard Http Port(80) Management	<ul style="list-style-type: none"> <li>Select unblock or block standard http port , default setting is <b>UNBLOCK(80)</b></li> <li>If other port sequence has to be set, select BLOCK, and then fill in the port sequence.</li> </ul>
Device Management IP Address	Display and set the device management IP address , default setting is <b>192.168.200.200</b>
Device Hostname	Fill in the device hostname, default setting is <b>CHIYU</b>
Device Location	Fill in the device location , default setting is <b>blank</b>
Administrator Password	<ul style="list-style-type: none"> <li>User Name : Fill in the user name</li> <li>Password Change : Change the password, for security reasons, please fill in a new password to replace the default management</li> <li>Password Confirm : Confirm the new password</li> </ul>
Block Ping Request	Select unblock or block ping request function , default setting is <b>unblock</b>
MAC Address Change	If you want to change the MAC address, fill in the new MAC address
Reset System to Factory Default	Execute this function will reset system to factory default
Reboot System	Execute this function will reboot system

## 2 · System Status Monitor



**BF-430 Status Monitor**

System Status	
Product Name:	BF430 232/485 TCP/IP Converter
Firmware Version:	1.13.00, Apr 4 2011
System Up Time:	2H:30M:31S

Ethernet Status	
IP Configuration Mode:	STATIC IP
Operation Mode:	TCP SERVER
Connection Port:	50000
MAC Address:	00:0e:e3:01:36:46
IP Address:	192.168.168.125
Subnet mask:	255.255.255.0
Default Gateway:	192.168.168.254
Primary DNS:	168.95.1.1
STATUS:	Up


Serial Status	
Serial Type:	RS232
Baud Rate:	19200
Data Bits:	8
Parity Check:	none
Stop Bits:	1
Flow Control:	None

Statistic	
Ethernet :	TX Bytes: 118152 bytes
	TX Packets: 204 packets
	RX Bytes: 9999445 bytes
	RX Packets: 106201 packets
Serial:	TX Bytes: 0 bytes
	RX Bytes: 0 bytes

### ● Function instruction

Function	Description
Product Name	Display the product name : <b>BF-430 232/485 TCP/IP Converter</b>
Firmware Version	Display the firmware version : <b>1.13.00, Apr 4 2011</b>
System Up Time	Display system up time , the sequence is <b>hour/minute/second</b>
Ethernet Status	
IP Configuration Mode	Display the IP configuration , default setting is <b>STATIC IP</b>
Operation Mode	Display the operation mode , default setting is <b>TCP SERVER</b>
Connection Port	Display the connection port , default setting is <b>50000</b>
MAC Address	Display the MAC address of BF-430
IP Address	Display BF-430 address, default setting is <b>192.168.168.125</b>
Subnet mask	Display BF-430 Subnet mask, default setting is <b>255.255.255.0</b>
Default Gateway	Display BF-430 Default Gateway, default setting is <b>192.168.168.254</b>
Primary DNS	Display BF-430 Primary DNS address, default setting is <b>168.95.1.1</b>
STATUS	Display BF-430 internet status
Serial Status	
Serial Type	Display Serial type, default setting is <b>RS232</b>
Baud Rate	Display Baud Rate, default setting is <b>19200</b>
Data Bits	Display Data Bits, default setting is <b>8</b>
Parity Check	Display Parity Check, default setting is <b>None</b>
Stop Bits	Display Stop Bits, default setting is <b>1</b>
Flow Control	Display Flow Control, default setting is <b>None</b>
Statistic	
Ethernet	RX / TX bytes and RX / TX packets display the total data amount of data receive and transmission of <b>Ethernet</b> .
Serial	RX & TX display the total data amount of data receive and transmission of <b>Serials</b> .


### 3 - Backup & Restore Configuration



● **Function instruction**

Function	Description
Backup	After execution, can save the present system settings as a backup file, and save it in hardware, the sub-name of the saved file is <a href="#">.cfg</a>
Restore	Browse and select saved file( <a href="#">.cfg</a> ), execute Restore to restore system settings


## 4、Firmware Upgrade



### ● Function instruction

Function	Description
Please select a file to upgrade	<ul style="list-style-type: none"> <li>● Browse and select firmware, execute Upgrade to upgrade firmware</li> <li>● Has to assure the possibility of power supply during the process of upgrading, or severe damage will be caused. What if upgrade different firmware to different products, and it will also cause severe damage.</li> </ul>

## 5、PING



**Networking Diagnostic (PING)**

Source IP Address :	192.168.168.125				
Destination IP Address :	0 . 0 . 0 . 0				
Packet Number :	4 (1 ~ 4)				
Packet Size :	60 (maximum 1460 Bytes)				
Ping Result :	<table border="1"> <tr> <td>Sent Request:</td> <td>0</td> </tr> <tr> <td>Receive Reply:</td> <td>0</td> </tr> </table>	Sent Request:	0	Receive Reply:	0
Sent Request:	0				
Receive Reply:	0				

PING CANCEL BACK

### ● Function instruction

Function	Description
Source IP Address	Display BF-430 IP address
Destination IP Address	Input IP address of Remote Host
Packet Number	Set up the number of PING package, ranged 1 ~4 , the default <b>4</b>
Ping Size	Set up the size of PING package, the utmost setting <b>1460 bytes</b> .
Ping Result	<ul style="list-style-type: none"> <li>● Display <b>Sent Request</b> data</li> <li>● Display <b>Receive Reply</b> data</li> </ul>